

DROP TEST

PHOSPHONATE EQUIVALENCE (PPM) ATMP (1.0); Na₅ATMP (1.3); HEDP (0.9); K₆HDTMP (1.2); DTPMP (1.45), Na₅DTPMP (1.7)

COMPONENTS:

1 x 5051	Instruction
1 x 9198P	Sample Tube, Graduated (25 mL) w/ cap & purple dot, plastic
1 x 9315	Test Paper, pH, 1.8-3.8, 200 strips
1 x R-0686P-C	Sulfuric Acid N, 2 oz w/ purple cap, DB
1 x R-0697-C	Thiosulfate N/10, 2 oz, DB
1 x R-0802P-I	Xylenol Orange Indicator Powder, 10 g
1 x R-0803-C	Phosphonate Titrating Solution, 2 oz, DB
1 x R-0805-C	Fluoride Masking Agent, 2 oz, DB

TO ORDER REPLACEMENT PARTS AND REAGENTS CALL TOLL-FREE
800-TEST KIT (800-837-8548).

PROCEDURE:

CAREFULLY READ AND FOLLOW PRECAUTIONS ON REAGENT LABELS.
KEEP REAGENTS AWAY FROM CHILDREN.

NOTE: When dispensing reagents from dropper bottles, **always** hold bottle in a vertical position.

NOTE: Iron can cause negative interference at a level greater than 5 ppm.
Orthophosphate and polyphosphate can cause positive interference at all levels.

NOTE: Run a blank using tap water. Normal blank requires about 2 drops of R-0803 Phosphonate Titrating Solution to reach endpoint.

Phosphonate Test

1. Rinse and fill 25 mL sample tube (#9198P) to 25 mL mark with water to be tested.
2. Add:
 - 1 drop R-0697 Thiosulfate N/10
 - 10 drops R-0805 Fluoride Masking Agent
 - 1 level dipper R-0802P Xylenol Orange Indicator Powder
 Swirl to mix.

3. Adjust pH between 2.6 and 3.0:

Add 1 drop R-0686P Sulfuric Acid N. Swirl to mix. Dip test paper (#9315) into sample, in direction of arrow, for 3 seconds, with all color zones immersed. Match indicator zone (unnumbered square between 2.7 and 3.0 color standards) with color scale. Read printed pH value. If necessary, continue adding R-0686P Sulfuric Acid N dropwise, swirling and checking pH with a new test paper after each drop, until a pH between 2.6 and 3.0 is obtained. Sample will be yellow (Fig. 1).

4. Add R-0803 Phosphonate Titrating Solution dropwise, swirling and counting after each drop, until color changes from yellow to purplish pink (Fig. 2).

5. Subtract drops of R-0803 Phosphonate Titrating Solution in blank from drops in sample (Step 4). Multiply by appropriate conversion factor (see CONVERSION FACTORS). Record as parts per million (ppm) phosphonate.

CONVERSION FACTORS:

To express phosphonate as:

Multiply drops by:

Aminotri(methylenephosphonic acid) (ATMP)	1.0
Aminotri(methylenephosphonic acid), pentasodium salt (Na ₅ ATMP)	1.3
1-Hydroxyethylidene-1,1-diphosphonic acid (HEDP)	0.9
Hexamethylenediaminetetra(methylenephosphonic acid), hexapotassium salt (K ₆ HDTMP)	1.2
Diethylenetriaminepenta(methylenephosphonic acid) (DTPMP)	1.45
Diethylenetriaminepenta(methylenephosphonic acid), pentasodium salt (Na ₅ DTPMP)	1.7



Fig. 1



Fig. 2



31 Loveton Circle, Sparks, MD 21152 USA
800-TEST KIT (837-8548) • 410-472-4340

120817