DROP TEST CHLORIDE (1 drop = 10 ppm)

COMPONENTS:

1 x 5212C Instruction

1 x 91980 Sample Tube, Graduated (25 mL) w/ cap & orange dot, plastic

1 x R-0630-C Chromate Indicator, 2 oz. DB

1 x R-0638O-A Phenolphthalein Indicator, .75 oz w/ orange cap, DB

1 x R-0706-C Silver Nitrate Reagent, 2 oz, DB

1 x R-0736O-C Sulfuric Acid .6N, 2 oz w/ orange cap, DB

TO ORDER REPLACEMENT PARTS AND REAGENTS CALL TOLL-FREE 800-TEST KIT (800-837-8548).

PROCEDURE:

CAREFULLY READ AND FOLLOW PRECAUTIONS ON REAGENT LABELS. KEEP REAGENTS AWAY FROM CHILDREN.

NOTE: When dispensing reagents from dropper bottles, always hold bottle in a vertical position.

Chloride Test

NOTE: When sulfite content of sample water to be tested exceeds 10 ppm, the sulfite should be oxidized to prevent interference in test. A 25 mL sample is first adjusted to the appropriate pH, then 1 mL (or 25 drops) of R-0649 Hydrogen Peroxide Solution (sold separately) is added and thoroughly mixed. Continue with the rest of the procedure.

- 1. Rinse and fill 25 mL sample tube (#91980) to 25 mL mark with water to be tested.
- 2. Add 2 drops R-0638O Phenolphthalein Indicator. If sample turns pink (Fig. 1), add R-07360 Sulfuric Acid .6N dropwise, swirling after each drop, until color changes from pink to colorless. If sample is colorless, proceed to Step 3.

- 3. Add 5 drops R-0630 Chromate Indicator, Swirl to mix, Sample will turn vellow (Fig. 2).
- 4. Add R-0706 Silver Nitrate Reagent dropwise, swirling and counting after each drop, until color changes from vellow to a milky salmon (brick red) (Fig. 3).

NOTE: A white precipitate will form as R-0706 Silver Nitrate Reagent is added to the sample. Do not add enough R-0706 Silver Nitrate Reagent to give a brown color. First change from yellow to a milky salmon (brick red) is the endpoint.

5. Multiply drops of R-0706 Silver Nitrate Reagent by 10. Record as parts per million (ppm) chloride (Cl⁻).



Fig. 1



Fig. 2



Fig. 3

